



## INSTALLATION INSTRUCTIONS FOR NUMBER DECALS (WET APPLICATION)

A professional installation is recommended as we are not responsible for errant installations.



1. Thoroughly wash vehicle. Prepare the application surface by removing dirt, debris, and any wax with a soft terry cloth and rubbing alcohol.

2. Place the decal where desired, ensuring you measure from two points on the MINI. *For example the bottom edge of the door to the bottom edge of the decal, and from the bonnet edge of the door to the inside edge of the decal.*



3. Place one long horizontal piece of tape on the top of the decal. Now using it like a hinge, peel back the REAR backing leaving the top film in place. Now LIGHTLY mist water over the application area and squeegee from the center of the decal outward toward the edges.

4. Be sure to take your time, removing all water and air from under the decal. After all air is removed, gently peel back the top film. Check the following day for air bubbles and remove them with a pin and the squeegee. Repeat these steps for the other side (if door decals).

### CARE AND MAINTENANCE:

**MIGHTYSTRIPES** does not recommend waxing over the decal. You have purchased a quality product. The vinyl is designed to withstand normal outdoor abuse and resists fading and cracking. Wash decal with automotive car wash as you would the rest of your vehicle.